

# What A/V Settings do I use?

*Note: The Beyonwiz can output a picture via HDMI, Component or Composite. You can toggle between the different output modes by pressing the TV-OUT button on the remote. Audio can be output via HDMI, S/PDIF (fibre optical cable) Coaxial and normal RCA cables.*

*If you don't know what option to select, just connect some RCA cables to the Composite Video (Yellow), FR (Red) and FL (White) ports on the Beyonwiz to the same INPUT ports on your TV. Switch your TV to AV Input mode, then press the TV-OUT button until you see a picture – **Please refer to Pages 11-12 in the manual for more information.***

1. Switch on the Beyonwiz PVR.
2. Press the SETUP button on the remote.
3. Using the ARROW keys on the remote, navigate to the CONFIG option on the top bar.
4. Make sure the highlighted item is A/V Output on the left column and press OK on the remote – the highlighted item should now be TV Aspect Ratio.



*Note: There are two different modes, 16:9 and 4:3. Most new LCD or Plasma TVs are 16:9, older style TVs are usually 4:3.*

5. Press OK on the remote then use the ARROW keys to highlight the mode for your TV then press OK.



*Note: If you selected 4:3, you can choose between letter box (black lines at top and bottom of the screen) or Pan and Scan (Picture cropped to fit the whole screen area) in the 16:9 Display Format option.*

6. Use the ARROW keys on the remote to navigate down the list to Video Type and press OK then use the ARROW keys to highlight PAL and press OK on the remote.

*Note: If you are using Composite video (yellow RCA), skip to step 8. If you are using Component or HDMI use the ARROW keys on the remote to navigate down the list to Component Video or HDMI video and press OK, then use the ARROW keys to highlight the resolution mode your TV supports.*

7. Use the ARROW keys on the remote to navigate down the list to Audio Format and press OK then use the ARROW keys to select the audio format.

Mode	Description	Use
> 2ch	Stereo Output	RCA connection to TV
> 5.1ch	5.1 Surround Sound Output	RCA connection to 5.1 surround speakers (usually connect all cables to the sub-woofer)
> passthrough	Audio passed via HDMI, S/PDIF or Coax to TV or Amp for decoding	HDMI to TV or S/PDIF / Coax direct to 5.1 Amplifier

8. Use the ARROW keys on the remote to navigate down the list to S/PDIF Output and press OK then use the ARROW keys to select > Enable if you are using a fibre optic cable to your Amplifier or TV for sound. Select > Disable if you are not using fibre optic output.
9. Use the ARROW keys on the remote to navigate down the list to AC3 Compression Mode and press OK then use the ARROW keys to select > RF Mode then press OK. Press LIVE to exit.