

# What's an EPG?

Note: EPG = Electronic Program Guide and is a list of TV programs. There are two ways to populate the EPG – via IceTV Guide or the EPG data broadcast by the networks.

1. Switch on the Beyonwiz PVR and wait for a picture to show on the screen. If a picture doesn't appear, your PVR may need to scan your channels first – See "How do I do a Channel Scan?"
2. Press the **GUIDE** button on the remote to bring up the **EPG**.
3. Press the **ARROW** keys to move around the **EPG** to show more services or later programs.
4. Use the **YELLOW** button to skip **forward 24 hours**, and the **GREEN** button to go **back 24 hours**. The **BLUE** button will return you to the **Current Event**.



5. Press the **RED** button on the remote to toggle the **Style** between single and multi service listing
6. To change to a channel, press **OK** while the service you want is highlighted and it will be displayed in the thumbnail view (top right corner).



7. To set a **timer**, highlight the show you wish to record and press the **REC** button on the remote.

8. If you press the **POP-UP** button, you can view the **Timer List** or **Recording Information**.

(refer to "How do I set, edit or delete a Timer?" and "How do I extend a running Timer" for more information) .



9. To view **information** about a program, highlight the program and press the **i** button on the remote (near the **VOL** and **CH**). Press the **i** button to return to the **EPG** list.

10. Press the **LIVE** button on the remote to resume normal viewing.



FOR MORE DETAILED INFORMATION REFER TO PAGE 63-66 OF THE MANUAL

FOR INFORMATION ON HOW TO SETUP ICETV GUIDE REFER TO

<http://www.icetv.com.au/support/setup/setupbeyonwiz.shtml>