


Remote Control HEXA Code Table

Remote Control HEXA Code Table

Model Code: BR-01



1	STANDBY	0xBE000AF5
2	EJECT	0xBE0040BF
3	STB	N/A
4	TV/RADIO	0xBE0055AA
5	TV-OUT	0xBE0042BD
6	TV	N/A
7	SETUP	0xBE0007F8
8	WizTV	0xBE0052AD
9	LIVE	0xBE0008F7
10	FILE PLAY	0xBE0044BB
11	VOL +/-	0xBE0002FD 0xBE0003FC
12	CH +/-	0xBE0000FF 0xBE0001FE
13	MUTE	0xBE000CF3
14	INFO	0xBE000DF2
15	FAV	0xBE0009F6
16	GUIDE	0xBE0043BC
17	POP-UP	0xBE001AE5
18	LIST	0xBE004CB3
19	EXIT	0xBE001CE3
20	UP/DOWN/ LEFT/RIGHT	0xBE004EB1 0xBE004FB0 0xBE0053AC 0xBE0054AB
21	OK	0xBE001FE0
22	RECALL	0xBE001EE1
23	RED	0xBE004DB2
24	GREEN	0xBE000DF2
25	YELLOW	0xBE000EF1
26	BLUE	0xBE000FF0
27	0/1/2/3/4/ 5/6/7/8/9	0xBE0010EF 0xBE0011EE 0xBE0012ED 0xBE0013EC 0xBE0014EB 0xBE0015EA 0xBE0016E9 0xBE0017E8 0xBE0018E7 0xBE0019E6
28	SLEEP	0xBE001BE4
29	ZOOM	0xBE0050AF
30	PLAY	0xBE004BB4
31	STOP	0xBE004AB5
32	PAUSE	0xBE0046B9
33	SLOW FWD	0xBE0006F9
34	REW	0xBE0045BA
35	FF	0xBE0048B7
36	PREV	0xBE0004FB
37	NEXT	0xBE0005FA
38	REC	0xBE005EA1
39	SUBTITLE	0xBE0047B8
40	TELETEXT	0xBE0051AE
41	SOUNDTRACK	0xBE0049B6