



Software Upgrade



This guide will take you through upgrading the software on your Beyonwiz T3. At this stage you will need to download the Firmware Image and unzip it to a USB stick to apply, in the near future you will be able to upgrade your Firmware Image directly over the internet, this guide will be modified with those instructions when the feature becomes available.

- Step 1.** Download the latest version of the T3 Firmware Image from either the downloads page at www.beyonwiz.com.au/downloads.php or in the Beyonwiz User Forum under Firmware Images in the T3 section. If you are viewing this How To guide in the Forum then the link to download the latest Firmware Image is at the top of this page.
- Step 2.** Copy and Paste the Downloaded file to a USB stick, it should not be inside a folder, it must be in the root of the USB stick.
- Step 3.** Unzip or Extract the Zip file to the USB stick, once extracted you should have a folder on the stick named 'beyonwiz', do not change the name of this folder.
- Step 4.** Make sure that your Beyonwiz T3 is in Shutdown mode or the rear switch is turned off, also make sure that no other USB devices are connected to the T3.
- Step 5.** Connect the USB stick to either the front or rear USB ports and power the T3 'ON'
- Steps 6.** You will get a message on the T3 Display 'Press OK to upgrade!', you **MUST** press the OK button on the front Touch Panel of the T3 itself, it will not work by using the Remote Control. You will then get a message "Flashing" or "Upgrading", **DONOT** turn the T3 off during the process, it will take anywhere from 1 - 5mins
- Step 7.** Once the Upgrade is complete your T3 will reboot, you may get another message to "Press OK to upgrade" again, you can just ignore this as it will go to booting after 5 - 10secs, when the display says booting you can remove the USB stick.