

Software Upgrade - T2/T3/T4

V16.1 - 20170310



This guide will take you through upgrading the software on your Beyonwiz T-Series (T2 / T3 / T4) via USB.

IMPORTANT MESSAGE FOR T3 OWNERS: The T3 must have the latest Bootloader installed or this Firmware Upgrade will not work. To check please press 'Menu' on your T3 remote and scroll to 'Information' and press 'OK' then Select 'About' and press 'OK' The Date of the Bootloader should be March 12, 2015. If the version is prior to this please go to www.beyonwiz.com.au/downloads and under T3 download and install the latest bootloader before proceeding.

***** 16.1 IS A MAJOR UPGRADE - ON FIRST BOOT WHEN ASKED TO RESTORE SETTINGS SELECT "NO" *****

- Step 1. Download the latest version of the Firmware Image by clicking on the link above that corresponds with your model.
- Step 2. Insert a USB stick into a USB slot on your computer, if there are previous Beyonwiz upgrade files on the stick you "Must" delete them. If it is a new USB stick that you have not used for an upgrade before you should format it in FAT32 format. Now Copy and Paste the Downloaded file to a USB stick, it should not be inside a folder, it must be in the root or top level of the USB stick.
* Tip: Older, small USB sticks seem to work the best.
- Step 3. Unzip or Extract the Zip file to the USB stick, once extracted you should have a folder on the stick named 'beyonwiz', do not change the name of this folder.
- Step 4. Make sure that your Beyonwiz is in Shutdown mode or the rear switch is turned off, also make sure that no other USB devices are connected to the PVR.
- Step 5. Connect the USB stick to either the front or rear USB ports and power the PVR 'ON' and watch the front display. *As the T2 does not have a front display your TV will need to be on and on the Beyonwiz PVR channel so that you can follow the onscreen instruction.
- Step 6. The Front Display and / or your TV will now advise you to press the UP Arrow on the front of the PVR to start the Update, do this now.
The process will be displayed on the PVR display and / or TV, it will display scrolling text such as "Flash Kernel" and "Flash Rootfs", DONOT turn the PVR off during the process, it will take anywhere from 5 - 10mins depending on the speed of your USB stick.
- Step 7. Once the Upgrade is complete the PVR front display and / or TV will show "Remove USB, Press Power." You now pull the USB out and press the Power button on the front Touch Panel, you can also switch the PVR off at the rear switch, wait 30seconds and switch back on.
- Step 8. Your PVR will now boot up into the Setup Wizard, if you backed up your settings you will be prompted to restore please select "NO" and set the PVR up from scratch by going through the Wizard again, any recordings you have will not be affected.

***** 16.1 IS A MAJOR UPGRADE - WHEN ASKED TO RESTORE SETTINGS SELECT "NO" *****