

How do I do a Channel Scan?


1. Switch on the Beyonwiz PVR and make sure an antenna is connected to the ANT IN port on the PVR (please see page 12 in the manual)

2. Press the SETUP button on the remote.
3. Using the ARROW keys on the remote, navigate to the CONFIG option on the top bar.
4. Using the ARROW keys navigate to Service Scan on the left column and press OK on the remote.



5. Use the ARROW keys to navigate down to highlight Start Scanning then press OK on the remote.

Note: A warning may appear asking you to confirm. Selecting YES will remove any previous timers. Selecting NO will return you to the previous screen, perhaps now is the best time to make a note of your timers.



6. The scanning will take about 2 or 3 mins. You can watch the progress bar fill from left to right.



7. When complete you should see a Notice to indicate the Service Scan is Complete.
8. Press OK to Dismiss.
9. Use the LIVE key on the remote to return to normal viewing.



Note: There are additional settings that may be required if requested by an antenna installer.

Option	Description	Normal Setting
Antenna DC	Some antennas have amplifiers that are powered via the coax cable. Only use this option if your antenna installer requires it.	OFF
Scanning Range	You can do a complete channel scan or a partial channel scan	FULL

FOR MORE DETAILED INFORMATION REFER TO PAGE 27 IN THE MANUAL