

# What is firmware and how do I update it?

Firmware is the operating system for the Beyonwiz. Upgrades are easily performed and this guide shows you how to upgrade the firmware on a Beyonwiz unit.

**Before you begin:** Please download the latest firmware from the downloads page of the [www.beyonwiz.com.au](http://www.beyonwiz.com.au) website and save it onto your Network, USB or Memory Card. Please refer to the relevant release notes (also available online) for more information on different firmware versions.

**Step 1:** Put the Beyonwiz into standby mode, then turn it on again. When both video & audio appear back on your TV, insert the USB or Memory Card into the Beyonwiz (USB/Memory cards not required for network upgrades).

**Step 2:** Press the “SETUP” button on the remote, then use the ◀▶ buttons to highlight the “System” (gears) option on the top bar.

**Step 3:** Use the ▲▼ buttons to select “Firmware” in the side menu (to the left), then press “OK”.

**Step 4:** Use the ▲▼ buttons to select “Firmware Upgrade”, then press “OK”.

**Step 5:** Use the ▲▼ buttons to select the media source for the upgrade (Network, USB or Memory Card), then press “OK”.

**Step 6:** Use the ▲▼ & “OK” buttons to navigate through & select the required firmware file, then press “OK” to verify the firmware.

**Step 7:** When the firmware has been verified use the ◀ button to highlight “YES”, then press “OK” to confirm and begin the upgrade. **Note:** The upgrade procedure has 2 parts (erasing and then writing). Do not turn the power off or interrupt the upgrade process.

**Step 8:** When the “firmware Successfully Upgraded” message appears, press “OK” to turn the Beyonwiz off and leave it in standby mode for a minute before turning it back on. The upgrade is now complete and USB/Memory device can be removed.



USB selected as the media source for the firmware upgrade (Step 5).



Confirming the upgrade (Step 7).



Old firmware being erased (Step 7 Note:).



“Firmware Successfully Upgraded” (Step 8).